

How to hang acrylic prints with drilled standoff posts



Measure the distance between the drilled holes.



With a level plot the holes on a wall.



Place the print over the holes to make sure they line up correctly*



Drill pilot holes for the drywall plugs



Hammer in drywall plus



Screw in bottom thread onto the wall



Screw the post onto the bottom thread



Place print on top of posts



Screw the caps onto the posts

* You could always skip steps 1 & 2 and simply hold the print up on the wall and mark the holes, but this can be hard to do (and get square) on one's own.